



BICKNELL
Racing Products

INSTRUCTIONS FOR BRP 9392 BIG BEARING HUB SPACER KIT

***** Pre assemble hub and bearing assembly dry with no grease and no seal *****

1. Install inner bearing and a .550 spacer on spindle snout
2. Install a .590 spacer
3. Slide hub on spindle with outer bearing and tighten hub nut. Nut should be tightened like a normal nut and not backed off.
4. Spin hub and feel for play by rocking hub.
5. If hub spins free with play, disassemble and replace .590 spacer with a narrower one.
6. If hub doesn't spin freely, disassemble and replace the .590 with a wider spacer
7. Repeat procedure changing spacers until hub spins freely with no play.
8. If needed, a fine adjustment can be made by switching the .550 spacer with a .552