



**MATCH ALIGNMENT LINE
ON CAP TO BODY**

**DRILL AND TAP THIS
HOLE AND PUT
BOLT INTO REAR
END TUBE**

3/8Fx1-1/4 SUPPLIED