



MATCH ALIGNMENT LINE  
ON CAP TO BODY

DRILL AND TAP THIS  
HOLE AND PUT  
BOLT INTO REAR  
END TUBE

3/8Fx1-1/4 SUPPLIED